



**Classic™ F2400M / S2400M
Freestanding Woodstove**

**Owners &
Installation Manual**



www.regency-fire.com
French Manual: <http://ow.ly/ZvmDk>
Manuel en Français: <http://ow.ly/ZvmDk>



F2400 Video

MODELS: F2400M S2400M

Tested by:



Installer: Please complete the details on the back cover
and leave this manual with the homeowner.

Homeowner: Please keep these instructions for future reference.

Thank-you for purchasing a **REGENCY FIREPLACE PRODUCT.**

The pride of workmanship that goes into each of our products will give you years of trouble-free enjoyment. Should you have any questions about your product that are not covered in this manual, please contact the REGENCY DEALER in your area. Keep those REGENCY FIRES burning.

"This wood heater has a manufacturer set minimum low burn rate that must not be altered. It is against federal regulations to alter this setting or otherwise operate this wood heater in a manner inconsistent with operating instructions in this manual." Failure to follow the manual details can lead to smoke and CO emissions spilling into the home. It is recommended to have monitors in areas that are expected to generate CO such as heater fuelling areas.

"U.S. ENVIRONMENTAL PROTECTION AGENCY Certified to comply with 2015 particulate emission standards using crib wood". Not approved for sale after May 15, 2020."

Model Regency F2400 and S2400 – 3.4 g /hr.

SAFETY NOTE: If this woodstove is not properly installed, a house fire may result. For your safety, follow the installation instructions, contact local building, fire officials, or authority having jurisdiction about restrictions and installation inspection requirements in your area.

The following statements are required by the Environmental Protection Agency:

"This manual describes the installation and operation of the Regency F2400 and S2400 wood heater. This heater meets the 2015 U.S. Environmental Protection Agency's crib wood emission limits for wood heaters. Under specific test conditions this heater has been shown to deliver heat at rates ranging from 12,000 BTU/hr. to 36,800 BTU/hr." This unit has been tested using 5G series and generates the best efficiency when operated using well-seasoned wood and installed in the main living areas where the majority of the chimney is within the building envelope and fully lined."

"It is against federal regulation to operate this wood heater in a manner inconsistent with operating instructions in this manual, or if any parts are removed. " It is against federal regulation to operate this wood heater in a manner inconsistent with operating instructions in this manual.

CAUTION: BURN UNTREATED WOOD ONLY. OTHER MATERIALS SUCH AS WOOD PRESERVATIVES, METAL FOILS, COAL, PLASTIC, GARBAGE, SULPHUR OR OIL MAY DAMAGE THE HEATER

"This heater is designed to burn natural wood only. Higher efficiencies and lower emissions generally result when burning air dried seasoned hardwoods, as compared to softwoods or to green or freshly cut hardwoods."

DO NOT BURN:

- Treated wood
- Coal
- Garbage
- Cardboard
- Solvents
- Colored Paper
- Trash
- Lawn clippings or yard waste
- Materials containing rubber including tires
- Materials containing plastic
- Waste petroleum products , paints or paint thinners or asphalt products
- Materials containing asbestos
- Construction or demolition debris
- Railroad ties
- Manure or animal remains
- Saltwater driftwood or other previously salt water saturated materials
- Unseasoned wood
- Paper products, cardboard, plywood or particle board. The prohibition against burning these materials does not prohibit the use of fire starters made from paper, cardboard, saw dust, wax and similar substances for the purpose of starting a fire in a wood heater

Burning these materials may result in release of toxic fumes or render the heater ineffective and cause smoke.

The authority having jurisdiction (such as Municipal Building Department, Fire Department, Fire Prevention Bureau, etc.) should be consulted before installation to determine the need to obtain a permit.

This unit must be connected to either a listed factory built chimney suitable for use with solid fuels and conforming to ULC629 in Canada or UL-103HT in the United States of America or code approved masonry chimney with flue liner.


F2400 and S2400 are tested and certified to ULC-S627-00 and UL1482-2011.

SAVE THESE INSTRUCTIONS



WARNING: Cancer and Reproductive Harm
www.P65Warnings.ca.gov

919-874



Modular Parts

ALL PICTURES / DIAGRAMS SHOWN THROUGHOUT THIS MANUAL ARE FOR ILLUSTRATION PURPOSES ONLY. ACTUAL PRODUCT MAY VARY DUE TO PRODUCT ENHANCEMENTS.



NATIONAL FIREPLACE INSTITUTE
NFI
CERTIFIED
www.nficertified.org

We recommend that our products be installed and serviced by professionals who are certified in the U.S. by the National Fireplace Institute® (NFI) or in Canada by Wood Energy Technical Training (WETT).



Wood Energy Technical Training
www.wettinc.ca



F2400 Video

4 | table of contents

| | | | |
|---|----|--|----|
| Safety Label for F2400m | 5 | Classic Door Handle | 21 |
| Safety Label for S2400M | 6 | Contemporary Door Handle | 21 |
| F2400M Unit Dimensions | 7 | Glass Installation | 21 |
| S2400M Unit Dimensions | 8 | Step-by-step Optional Accessories Installation | 21 |
| Wood Stove Outside Air Dimensions | 9 | Screen Door | 22 |
| Residential Installation | 10 | Seasoned wood | 23 |
| Modular Installation Options | 10 | Operating Instructions | 24 |
| Room Air | 11 | Draft Control | 24 |
| Important | 11 | First Fire | 24 |
| Minimum Clearance To Combustible Materials | 11 | Fan Operation | 25 |
| Stove Assembly Prior To Installation | 13 | Ash Disposal | 25 |
| Step-by-step Chimney And Connector Installation | 14 | Safety Guidelines and Warnings | 25 |
| Masonry Chimney | 15 | Maintenance | 26 |
| Masonry Fireplace | 15 | Creosote | 26 |
| Factory Built Chimney | 15 | Maintenance Of Nickel-plated Doors | 26 |
| Combustible Wall Chimney | | Latch Adjustment | 26 |
| Connector Pass-throughs | 16 | Door Gasket | 26 |
| Recommended Heights For Woodstove Flue | 17 | Glass Maintenance | 26 |
| Mobile Home Installation | 18 | Wood Storage | 26 |
| Listed Components For Mobile Home | | F2400m Stove Main Assembly w/classic door | 27 |
| Installation | 19 | F2400m Stove Main Assembly w/contemporary door | 28 |
| Flue Baffle & Secondary Air Tube Installation | 19 | S2400m Step Stove Main Assembly w/classic door | 29 |
| Stainless steel smoke deflector | | S2400m Step Stove Main Assembly | |
| adjustment / replacement | 20 | w/contemporary door | 30 |
| Brick Installation | 21 | Pedestal, Bottom Shield & Leg Options | 31 |
| | | Firebrick | 32 |
| | | Warranty | 34 |

This is a copy of the label that accompanies each Regency Freestanding Woodstove (F2400M). We have printed a copy of the contents here for your review.

NOTE: Regency units are constantly being improved. Check the label on the unit and if there is a difference, the label on the unit is the correct one.

SAFETY LABEL FOR F2400M

244

DO NOT REMOVE THIS LABEL / NE RETIREZ PAS CETTE ÉTIQUETTE

244

MODEL: REGENCY MEDIUM FREESTANDING STOVE - F2400M

TESTED TO: UL-1482-2011 / ILC-S627-00 / UL-737-2011 REPORT NO.219-S-02-2

THE F2400M MEETS UL737 STANDARD FOR FIREPLACE STOVES WHEN A FIRESCREEN IS PROVIDED.

INSTALL AND USE ONLY IN ACCORDANCE WITH THE MANUFACTURER'S INSTALLATION AND OPERATING INSTRUCTIONS. CONTACT LOCAL BUILDING OR FIRE OFFICIAL ABOUT RESTRICTIONS AND INSTALLATION INSPECTION IN YOUR AREA. USE 150 MM (6 IN.) DIAMETER MINIMUM 24 MSG BLACK OR 26 MSG BLUED STEEL CONNECTOR WITH LISTED UL103 HT FACTORY-BUILT CHIMNEY SUITABLE FOR USE WITH SOLID FUELS OR MASONRY CHIMNEY. SEE LOCAL BUILDING CODE AND MANUFACTURER'S INSTRUCTIONS FOR PRECAUTIONS REQUIRED FOR PASSING A CHIMNEY THROUGH A COMBUSTIBLE WALL OR CEILING. DO NOT PASS CHIMNEY CONNECTOR THROUGH COMBUSTIBLE WALL OR CEILING. DO NOT CONNECT THIS UNIT TO A CHIMNEY FLUE SERVING ANOTHER APPLIANCE. INSTALLER ET UTILISER SEULEMENT SELON LES INSTRUCTIONS D'INSTALLATION ET D'UTILISATION DU FABRICANT. CONTACTER LES RESPONSABLES DU BÂTIMENT OU DU SERVICE INCENDIE DE VOTRE RÉGION POUR CONNAÎTRE LES RESTRICTIONS ET EXIGENCES D'INSPECTION DANS VOTRE RÉGION. UTILISER UN CONNECTEUR D'UN DIAMÈTRE MINIMAL DE 150 MM (6 PO) 24 MSG EN ACIER NOIR OU 26 MSG EN ACIER BRONZÉ AVEC CHEMINÉE PRÉFABRIQUÉE HOMOLOGUÉE UL-103 HT CONÇUE POUR UTILISATION AVEC COMBUSTIBLES SOLIDES OU UNE CHEMINÉE DE MAÇONNERIE. VOIR LE CODE DU BÂTIMENT LOCAL ET LES INSTRUCTIONS DU FABRICANT CONCERNANT LES PRÉCAUTIONS EXIGÉES POUR INSTALLER UNE CHEMINÉE TRAVERSANT UN MUR OU PLAFOND EN MATÉRIAUX COMBUSTIBLES. NE FAITES PAS TRAVERSER LE CONNECTEUR DE CHEMINÉE DANS UN MUR OU PLAFOND EN MATÉRIAUX COMBUSTIBLES. NE RACCORDEZ PAS CE POÊLE À BOIS À UN CONDUIT DE CHEMINÉE DESERVANT UN AUTRE APPAREIL.

F2400M WITH AIRMATE SHIELD

F2400M WITHOUT AIRMATE SHIELD

MINIMUM ALCOVE CEILING HEIGHT: 2.15 M / 7 FT MAXIMUM ALCOVE DEPTH 915 MM / 36 IN.
THE SPACE BENEATH THE HEATER MUST NOT BE OBSTRUCTED. OPERATE ONLY WITH FIREBRICKS IN PLACE.
FOR USE WITH SOLID WOOD FUEL ONLY. USE OF OTHER FUELS MAY DAMAGE HEATER AND CREATE A HAZARDOUS CONDITION. DO NOT OBSTRUCT COMBUSTION AIR OPENINGS. OPERATE ONLY WITH FIREBRICKS IN PLACE. RISK OF SMOKE AND FLAME SPILLAGE. OPERATE ONLY WITH DOORS FULLY OPEN OR FULLY CLOSED. IF INSTALLED IN A MOBILE HOME OPERATE ONLY WITH DOORS FULLY CLOSED. OPEN FEED DOOR TO FEED FUEL ONLY WHEN OPERATED WITH DOORS OPEN. THE MANUFACTURER'S SUPPLIED SCREEN MUST BE USED. DO NOT USE GRATE OR ELEVATE FIRE. BUILD WOOD FIRE DIRECTLY ON HEARTH. DO NOT OVERFIRE. IF HEATER OR CHIMNEY CONNECTOR GLOWS YOU ARE OVERFIRING. INSPECT AND CLEAN CHIMNEY AND CONNECTOR FREQUENTLY. UNDER CERTAIN CONDITIONS OF USE CREOSOTE BUILDUP MAY OCCUR RAPIDLY. KEEP FURNISHINGS AND OTHER COMBUSTIBLE MATERIAL AWAY FROM HEATER. REPLACE GLASS ONLY WITH NECESSARY GLASS. COMBUSTIBLE FLOOR MUST BE PROTECTED BY NON-COMBUSTIBLE MATERIAL EXTENDING BENEATH THE HEATER AND TO THE FRONT AND SIDES AS INDICATED OR TO THE NEAREST PERMITTED COMBUSTIBLE MATERIAL.

OPTIONAL COMPONENT: FAN (846-515), ELECTRICAL RATING: VOLTS 115, 60 HZ, 2 AMPS, SCREEN DOOR (846-191)
DANGER: RISK OF ELECTRIC SHOCK. DISCONNECT POWER BEFORE SERVICING UNIT. DO NOT ROUTE POWER CORD UNDER OR IN FRONT OF APPLIANCE.
COMPONENTS REQUIRED FOR MOBILE HOME INSTALLATION: OUTSIDE AIR KIT AND ONE OF THE FOLLOWING DOUBLE WALL CONNECTOR.
IN CANADA: LISTED SECURITY MODEL DP OR OLIVER MACLEOD PRO-VENT PV DOUBLE WALLED CONNECTOR WITH LISTED CHIMNEY SYSTEM: SECURITY MODEL S2100, ICC EXCEL 2100, SELKIRK SENTINAL CF.
IN USA: LISTED DOUBLE WALL CONNECTORS SECURITY MODEL DP, SELKIRK MODEL DS, OLIVER MACLEOD PRO VENT PV, SIMPSON DURA VENT MODEL DVL, GSW SUPER PIPE & METAL-FAB DOUBLE WALL, CONNECTED TO ONE OF THE FOLLOWING COMPATIBLE CHIMNEY SYSTEMS: SECURITY MODEL S2100 OR MODEL ASHT, SELKIRK MODEL SSI, OLIVER MACLEOD PRO JET 3103, SIMPSON DURA PLUS, GSW MODEL SC OR METAL-FAB TEMP GUARD, AMERI-TEC HS, ICC EXCEL 2100. USE CHIMNEY COMPONENTS AS SPECIFIED IN INSTALLATION INSTRUCTIONS.

AUTOUR MINIMALE DU PLAFOND DE L'ALCÔVE: 2.15 M / 7 FT PROFONDEUR MAXIMALE DE L'ALCÔVE: 915 MM / 36 PO
DÉGAGEMENT MINIMAL DU PLAFOND POUR UN CONNECTEUR HORIZONTAL: 455 MM / 18 PO
L'ESPACE AU-DESSOUS DU POÊLE NE DOIT PAS ÊTRE OBSTRUÉ. UTILISER SEULEMENT AVEC LES BRIQUES RÉFRACTAIRES EN PLACE.
POUR UTILISATION AVEC BOIS SOLIDE SEULEMENT. L'UTILISATION D'AUTRES COMBUSTIBLES PEUT ENDOMMAGER LE POÊLE ET CRÉER UNE CONDITION DANGEREUSE. NE PAS OBSTRUER LES OUVERTURES D'AIR DE COMBUSTION. UTILISER SEULEMENT AVEC LA PORTE FERMÉE - OUVRIRE LA PORTE DE CHARGEMENT POUR ALIMENTER LE FEU SEULEMENT. NE PAS UTILISER DE GRILLE À BOÎCHES NI S'ÉLEVÉ LE FEU. MONTER LE FEU DE BOIS DIRECTEMENT SUR L'ÂTRE. NE PAS SURCHAUFFER - SI LE POÊLE OU LE CONNECTEUR DE CHEMINÉE SE MET À ROUGIR, VOUS SURCHAUFFEZ. INSPECTEZ ET NETTOYEZ FRÉQUEMMENT LA CHEMINÉE ET LE CONNECTEUR EN CERTAINES CONDITIONS D'UTILISATION, UN DÉPÔT DE CRÉOSOTE PEUT SE FORMER RAPIDEMENT. GARDEZ LES MEUBLES ET AUTRES MATÉRIAUX COMBUSTIBLES ÉLOIGNÉS DU POÊLE. REMPLACEZ LA VITRE SEULEMENT PAR DU VERRE EN NEODERAM. LE PLANCHER COMBUSTIBLE DOIT ÊTRE PROTÉGÉ PAR DES MATÉRIAUX NON COMBUSTIBLES DÉPASSANT DU DESSOUS, DU DEVANT ET DES CÔTÉS DU POÊLE, TEL QU'INDIQUÉ, OU JUSQU'AU MATÉRIAU COMBUSTIBLE LE PLUS PRÈS PERMIS. COMPOSANTS EN OPTION: VENTILATEUR (846-515), ALIMENTATION ÉLECTRIQUE: 115 VOLTS, 60 HZ, 2 AMP.
DANGER: RISQUE D'ÉLECTROCUTION. DÉCONNECTER L'ALIMENTATION ÉLECTRIQUE AVANT DE FAIRE L'ENTRETIEN DU POÊLE. NE PAS INSTALLER LE CORDON ÉLECTRIQUE SOUS OU DEVANT L'APPAREIL.
COMPOSANTS EXIGÉS POUR INSTALLATION DANS UNE MAISON MOBILE: KIT DE PRISE D'AIR EXTÉRIEUR ET L'UN DES CONNECTEURS DE CHEMINÉE À DOUBLE PAROI SUIVANTS:
AU CANADA: CONNECTEURS DE CHEMINÉE HOMOLOGUÉS À DOUBLE PAROI: SECURITY MODÈLE DP OU OLIVER MACLEOD PRO-VENT PV AVEC SYSTÈME DE CHEMINÉE HOMOLOGUÉE: SECURITY MODÈLE S2100, ICC EXCEL 2100, SUPER VENT 2100, SUPERRPO 2100, CF SENTINAL.
AUX ÉTATS-UNIS: CONNECTEURS DE CHEMINÉE HOMOLOGUÉS À DOUBLE PAROI: SECURITY MODÈLE DP, SELKIRK MODÈLE DS, OLIVER MACLEOD PRO VENT PV, SIMPSON DURA VENT MODÈLE DVL, GSW SUPER PIPE & METAL-FAB À DOUBLE PAROI, CONNECTÉ À L'UN DES SYSTÈMES DE CHEMINÉE COMPATIBLES SUIVANTS: SECURITY MODÈLE S2100 OU MODÈLE ASHT, SELKIRK MODÈLE SSI, OLIVER MACLEOD PRO JET 3103, SIMPSON DURA PLUS, GSW MODÈLE SC OU METAL-FAB TEMP GUARD, AMERI-TECHS, ICC EXCEL 2100, SIMPSON DURA PLUS HT. UTILISER LES COMPOSANTS DE CHEMINÉE SPÉCIFIÉS DANS LES INSTRUCTIONS D'INSTALLATION.
MADE IN CANADA / FAIT AU CANADA

| MINIMUM CLEARANCES TO COMBUSTIBLE MATERIALS DÉGAGEMENTS MINIMUMS AUX MATÉRIAUX COMBUSTIBLES | | | | | |
|--|-------------------------|-------------------------------|-------------------------|-------------------|--------------------|
| F2400M WITH AIRMATE SHIELD | | F2400M WITHOUT AIRMATE SHIELD | | | |
| MEASURE FROM | FLUE HEATER CENTER-LINE | MEASURE FROM | FLUE HEATER CENTER-LINE | | |
| RESIDENTIAL INSTALLATION USING SINGLE WALL CONNECTOR | | | | | |
| SIDEWALL | A 406 mm / 16 in | D 711 mm / 28 in | SIDEWALL | A 457 mm / 18 in | D 762 mm / 30 in |
| BACKWALL | B 280 mm / 11 in | E 444 mm / 17.5 in | BACKWALL | B 305 mm / 12 in | E 470 mm / 18.5 in |
| CORNER | C 152 mm / 6 in | F 444 mm / 17.5 in | CORNER | C 155 mm / 6.5 in | F 457 mm / 18 in |
| INSTALLATION USING LISTED DOUBLE WALL CONNECTOR - MOBILE HOME | | | | | |
| SIDEWALL | A 380 mm / 15 in | D 685 mm / 27 in | SIDEWALL | A 380 mm / 15 in | D 685 mm / 27 in |
| BACKWALL | B 140 mm / 5.5 in | E 394 mm / 12 in | BACKWALL | B 165 mm / 6.5 in | E 330 mm / 13 in |
| CORNER | C 102 mm / 4 in | F 393 mm / 15.5 in | CORNER | C 152 mm / 6 in | F 444 mm / 17.5 in |
| INSTALLATION USING LISTED DOUBLE WALL CONNECTOR - RESIDENTIAL CLOSE CLEARANCE | | | | | |
| SIDEWALL | A 380 mm / 15 in | D 685 mm / 27 in | SIDEWALL | A 380 mm / 15 in | D 685 mm / 27 in |
| BACKWALL | B 140 mm / 5.5 in | E 394 mm / 12 in | BACKWALL | B 165 mm / 6.5 in | E 330 mm / 13 in |
| CORNER | C 102 mm / 4 in | F 393 mm / 15.5 in | CORNER | C 152 mm / 6 in | F 444 mm / 17.5 in |
| INSTALLATION USING LISTED DOUBLE WALL CONNECTOR - ALCOVE | | | | | |
| SIDEWALL | G 380 mm / 15 in | I 685 mm / 27 in | SIDEWALL | G 380 mm / 15 in | I 685 mm / 27 in |
| BACKWALL | H 140 mm / 5.5 in | J 394 mm / 12 in | BACKWALL | H 165 mm / 6.5 in | J 330 mm / 13 in |

FLOOR PROTECTION* PROTECTION DE PLANCHER*

BACK M K 405 mm / 16 in
SIDE L 150 mm / 6 in
FRONT N 150 mm / 6 in

* In Canada, floor protection must extend 18" (450mm) to the front and 8" (200mm) to each side and back of the stove.
* Au Canada, la protection de plancher doit dépasser de 18 po (457 mm) à l'avant et de 8 po (200 mm) de chaque côté du poêle et derrière le poêle.

CAUTION
HOT WHILE IN OPERATION DO NOT TOUCH. KEEP CHILDREN, CLOTHING AND FURNITURE AWAY. CONTACT MAY CAUSE SKIN BURNS. READ NAMEPLATE AND INSTRUCTIONS.
ATTENTION
CHAUD DURANT LE FONCTIONNEMENT. NE TOUCHEZ PAS. ÉLOIGNEZ LES ENFANTS, LES VÊTEMENTS ET LES MEUBLES. LE CONTACT PEUT CAUSER DES BRÛLURES DE LA PEAU. LISEZ LA PLAQUE SIGNALÉTIQUE ET LES INSTRUCTIONS

REGENCY
FIREPLACE PRODUCTS

MANUFACTURED BY / FABRIQUÉ PAR:
FPI FIREPLACE PRODUCTS INTERNATIONAL LTD.
6988 VENTURE ST.
DELTA, BC V4G 1H4

918-1721

DATE OF MANUFACTURE / DATE DE FABRICATION: 2017 2018 2019 2020 2021

This is a copy of the label that accompanies each Regency Medium Freestanding Step Stove (S2400M). We have printed a copy of the contents here for your review.


NOTE: Regency units are constantly being improved. Check the label on the unit and if there is a difference, the label on the unit is the correct one.

SAFETY LABEL FOR S2400M


[illegible]

F2400M UNIT DIMENSIONS

Contemporary Door




Classic Door




S2400M UNIT DIMENSIONS


Contemporary Door



Classic Door




WOOD STOVE OUTSIDE AIR DIMENSIONS



With pedestal from base of unit to centerline
4-1/2" (114mm)

Front



With bottom heat shield from rear heat shield to centerline
6-3/4" (171mm)

RESIDENTIAL INSTALLATION

- 1) Please read this entire manual before you install and use your new woodstove. Failure to follow instructions may result in property damage, bodily injury or even death. Be aware that local Codes and Regulations may override some items in this manual. Check with your local inspector.
- 2) Select a position for your Regency Stove. Consult the minimum clearance chart for your model and set the stove in place. For close clearance installation use listed double wall connector systems.
- 3) To insure vertical alignment, suspend a plumb bob from the ceiling over the exact center of your stove flue and mark a spot on the ceiling to indicate the center of the chimney.
- 4) Check that the area above the ceiling is clear for cutting. Re-confirm the clearance from the stove to combustibles to insure that they are within the prescribed limits.
- 5) This woodstove must be connected to a UL 103 HT (ULC S629) listed chimney or a code approved masonry chimney with a flue liner.
- 6) Install chimney according to chimney manufacturers instructions. The performance of your woodstove is governed to a very large part by the chimney system. Too short a chimney can cause difficult start-up, dirty glass, back smoking when door is open, and even reduced heat output.

Too tall a chimney may prompt excessive draft which can result in very short burn times and excessive heat output. The use of an inexpensive flue pipe damper may be helpful in reducing excessive draft.

CAUTION: The chimney should be the same size as the 6" flue outlet on the stove. The chimney must be listed as suitable for use with solid fuels. For other types of chimneys check with your local building code officials. Do not confuse a chimney with a type "B" Venting System used for gas appliances as suitable for a wood burning appliance. For Mobile Home installations refer to that section within this manual.

- 7) Mark the location of the pedestal base or legs on the floor, then move the stove aside and mark the position of the floor protector.
- 8) The floor protector must be of non-combustible material and must extend 16" (406mm) in front of the door opening and 6" (152mm) to the sides and rear of the unit. Some areas may require a larger size floor protector. See your local inspector. For outside air installation refer to Mobile Home installation instructions within this manual.
- 9) When the floor protection is complete, position the stove with the flue collar centered under the installed chimney.

NOTE: In Canada, floor protection must extend 18" (450mm) to the front and 8" (200mm) to each side and back of the stove.

- 10) In areas of seismic activity, Regency recommends that your unit is secured to the floor by using the bolt down holes inside the pedestal (the same ones used in Mobile Home installations).
- 11) For residential installations using 6" "C" Vent (single wall) the chimney connector must be at least 24 gauge steel. Do not use galvanized pipe. For Mobile Home installation refer to the Mobile Home installation instructions within this manual.
- 12) **Do not connect this unit to a chimney serving another appliance.**
- 13) A chimney connector cannot pass through an attic or roof space, closet or similar concealed space, or a floor, ceiling, wall or partition of combustible construction. In Canada, if passage through a wall, or partition of combustible construction is desired, the installation shall conform to CAN/CSA-B365, Installation Code for Solid-Fuel-Burning Appliances and Equipment.
- 14) Your Regency Woodstove is not to be connected to any air distribution duct.

MODULAR INSTALLATION OPTIONS

WARNING: ONLY USE SPECIFIED COMPONENTS.

The following items are required when assembling your Regency Stove. F2400 unit - the Rear Heat Deflector is supplied with the stove, but if you choose not to use it you must use the Airmate instead.

| | |
|--|---|
| Modular Part | Clearances are different. Generally you can get closer clearances with the airmate than with the rear heat deflector. |
| Airmate OR Rear Heat Deflector | Convection heat with Airmate vs. Radiant Heat with Rear Heat Deflector. The Airmate pushes heat forward out into the room, the Rear Heat Deflector deflects the heat upward. Refer to the Installation sections within this manual. |
| Pedestal or Legs | There are no performance differences with either the pedestal or legs. It is primarily a personal preference. Legs can be either painted steel or painted cast. Leg installation requires the bottom shield. |
| OPTIONS: These can be installed at time of installation or added later: | |
| Blower/Fan | Adding the blower will increase the area heated by the stove, it can move warm air beyond the room where the stove is located. |
| Ash Drawer Kit | Adding the Ash Drawer Kit makes cleaning ashes out of the stove easier and cleaner (refer to Bottom Shield Ash Drawer Kit, Installation section). |
| Screen Door | A simple add-on option that will allow you to enjoy the sound, warmth and view of an open fire. |

ROOM AIR IMPORTANT

For installation using room air for combustion, remove knockout from the pedestal, and/or from the bottom if using a heat shield.

Mobile home installations require the use of outside air.

outside air may be adapted to the unit. If using the bottom of the pedestal, do not remove knockout from the rear of the pedestal. Only remove rear knockout if outside air will be brought in from the rear.

On leg units outside air can only be brought in from the bottom of the heat shield.

Note: Once the knockout is removed there

are two tabs remaining. Bend both tabs out for ease of installation when attaching outside air.

On pedestal units there are two locations where

MINIMUM CLEARANCE TO COMBUSTIBLE MATERIALS


Please read the section below carefully as clearances depend on whether the airmate or the rear heat deflector is installed on the stove.

Measurements "From Unit" are from the top plate of the stove to a side wall or to a corner, and from the rear heat shield to a back wall.

Clearances may only be reduced by means approved by the regulatory authority.

NOTE: This clearance is also required for air space between the appliance and wall/ceiling.

NOTE: Be aware that local Codes and Regulations may override some clearances listed in this manual. Check with your local inspector.




| Residential Installation "C" Vent (Single Wall) | | | | | | |
|---|--------------|---------------|---------------|--------------|-----------------------|----------------|
| Unit | From Unit | | From Corner | | From Flue Center-Line | |
| | A | B | C | D | E | F |
| Medium F2400M with Airmate | 16" (406 mm) | 11" (280 mm) | 6" (152 mm) | 28" (710 mm) | 17.5" (444 mm) | 17.5" (444 mm) |
| with Rear Deflector | 18" (457 mm) | 12" (304 mm) | 6.5" (165 mm) | 30" (762 mm) | 18.5" (470 mm) | 19.5" (495 mm) |
| Medium S2400M Step Stove | 16" (406 mm) | 11" (279 mm) | 6" (152 mm) | 28" (710 mm) | 17.5" (432 mm) | 19" (483 mm) |
| Residential Close Clearance (To be installed with required pipe components) | | | | | | |
| When the stove is installed as a close clearance residential unit, a listed double wall connector is required from the stove collar to the ceiling level. | | | | | | |
| Unit | From Unit | | From Corner | | From Flue Center-Line | |
| | A | B | C | D | E | F |
| Medium F2400M with Airmate | 15" (381 mm) | 5.5" (139 mm) | 4" (101 mm) | 27" (685 mm) | 12" (304 mm) | 15.5" (393 mm) |
| with Rear Deflector | 15" (381 mm) | 6.5" (165 mm) | 6" (152 mm) | 27" (685 mm) | 13" (330 mm) | 17.5" (444 mm) |
| Medium S2400M Step Stove | 15" (381 mm) | 5.5" (139 mm) | 4" (101 mm) | 27" (685 mm) | 12" (304 mm) | 17" (432 mm) |
| Mobile Home Close Clearance (To be installed with required pipe components) | | | | | | |
| "C" Vent single wall pipe is not approved for Mobile Home installations. (Refer to Mobile Home Instructions.) | | | | | | |
| Unit | From Unit | | From Corner | | From Flue Center-Line | |
| | A | B | C | D | E | F |
| Medium F2400M with Airmate | 15" (381 mm) | 5.5" (139 mm) | 4" (101 mm) | 27" (685 mm) | 12" (304 mm) | 15.5" (393 mm) |
| with Rear Deflector | 15" (381 mm) | 6.5" (165 mm) | 6" (152 mm) | 27" (685 mm) | 13" (330 mm) | 17.5" (444 mm) |
| Medium S2400M Step Stove | 15" (381 mm) | 5.5" (139 mm) | 4" (101 mm) | 27" (685 mm) | 12" (304 mm) | 17" (432 mm) |

Minimum Alcove Clearance and Clearance to Combustible Materials

The Regency Freestanding models have been alcove approved and must be installed with a listed double wall connector to the ceiling level.

Note: Minimum alcove ceiling height - 84"
Maximum depth of alcove - 36"

NOTE: This clearance is also required for air space between the appliance and wall/ceiling.




| Unit | From Unit | | From Corner | | From Flue Center-Line | |
|-----------------------------------|--------------|---------------|--------------|--------------|-----------------------|---------------|
| | G | H | I | J | K | L |
| Medium F2400M with Airmate | 15" (381 mm) | 5.5" (139 mm) | 27" (685 mm) | 12" (304 mm) | 54" (1371 mm) | 48" (1219 mm) |
| with Rear Deflector | 15" (381 mm) | 6.5" (165 mm) | 27" (685 mm) | 13" (330 mm) | 54" (1371 mm) | 49" (1244 mm) |
| Medium S2400M Step Stove | 15" (381 mm) | 5.5" (139 mm) | 27" (685 mm) | 12" (304 mm) | 54" (1371 mm) | 48" (1219 mm) |

Floor Protection (Ember Protection only required)

A combustible floor must be protected by non-combustible material (like tile, concrete board, or certified to UL-1618 or as defined by local codes) extending beneath the heater and a minimum of 6" (152mm) from each side and minimum 16" (406mm) from the front face of the stove and minimum 6" (or the rear clearance to combustibles whichever is smaller) from the rear of the stove.

When installed with horizontal venting, non-combustible floor protection must beneath the flue pipe and extend 2" (51mm) beyond each side.



for angled corners

Minimum Overall Width (X) of Floor Protector for all installations:

| | | |
|------------|--------|--------------|
| Stove | F2400M | 36" (914 mm) |
| Step Stove | S2400M | 36" (914 mm) |

NOTE: In Canada, floor protection must extend 18" (450mm) to the front and 8" (200mm) to each side and back of the stove.

| Minimum Overall Depth (Y) of Floor Protector | | | | | | | | |
|--|----------------------|-------------|-----------------------------|-------------|-----------------------------|-------------|---------------|-------------|
| Unit | Residential "C" Vent | | Residential Close Clearance | | Mobile Home Close Clearance | | Alcove | |
| | Y | Z | Y | Z | Y | Z | Y | Z |
| Medium F2400M with Airmate | 46" (1168 mm) | 6" (152 mm) | 45" (1143 mm) | 5" (127 mm) | 45" (1143 mm) | 5" (127 mm) | 45" (1143 mm) | 5" (127 mm) |
| with Rear Deflector | 46" (1168 mm) | 6" (152 mm) | 45" (1143 mm) | 5" (127 mm) | 45" (1143 mm) | 5" (127 mm) | 45" (1143 mm) | 5" (127 mm) |
| Medium S2400M Step Stove | 46" (1168 mm) | 6" (152 mm) | 45" (1143 mm) | 5" (127 mm) | 45" (1143 mm) | 5" (127 mm) | 45" (1143 mm) | 5" (127 mm) |

* The rear clearance to combustibles is less than 6" (for corner installations the rear corners may be angled to take advantage of the closer clearances).

STOVE ASSEMBLY PRIOR TO INSTALLATION

All units require either the pedestal or 4 legs attached to the base. The F2400M stove requires either the Airmate or Rear Heat Deflector on top of the stove. Clearances to combustible materials vary depending on whether the airmate or rear heat deflector is installed, so be sure to check the Minimum Clearances, Installation section.

Airmate Assembly for F2400M (850-105)

- 1) The airmate sits on top of the stove with the slots in the sides fitting over the curved deflector on the rear stove top. See diagram 1. Discard the Rear Heat Deflector that is supplied with the unit, it is not required if the airmate is installed.
- 2) Center the airmate and push it forward to the front of the stove. The back of the airmate should be level with the back and sides of the rear heat shield. See Diagrams 2 & 3.




Diagram 1
Shown with classic door




Diagram 2




Diagram 3

Rear Heat Deflector Assembly for F2400M (815-555)

The rear heat deflector is supplied with the stove and must be installed unless the optional airmate has been selected. It stops the heat radiated from the flue collar from overheating the rear wall. The rear heat deflector is installed on top of the rear heat shield, as shown in Diagram 4.





Diagram 4
Shown with classic door

Side Shield Adjustment

The left and right side shields are lowered for shipping and handling. It allows for a handhold on the top of the stove. Before placing in the Step Stove in its final position, the side shields must be raised.

Loosen the screws on the rear on the stove (3 per side), slide the side panel up as far as possible and then secure by tightening the screws.




Pedestal Assembly F2400M & S2400M (020-925)

- 1) For easier assembly, tip the stove on its back (onto a soft surface to prevent scratching).


Hint: If you have chosen the Ash Drawer option, remove the ash dump cover plates (knockout) before attaching the pedestal. See page 17 "Ashdrawer Kit Installation".

- 2) **Important:** Remove the blanking plate if
 - a) you are **not** installing outside combustion air or
 - b) outside air is to be brought in from the **rear** of the stove (see below).

- 3) Unscrew the 4 bolts in the under-side of the stove. Align the holes in the corners of the pedestal top with the corresponding holes in the base of the stove. Fasten using a bolt and washer for each corner.



- 4) Push the Regency logo into the two holes in the front bottom left corner of the pedestal cover plate.



Note: Any paint touch up should be done prior to placing logo on pedestal.

- 5) If not using ash drawer, then cover plate must be installed. If using ash drawer, then disregard cover plate.

Leg and Bottom Shield Assembly F2400M & S2400M

Bottom Shield 020-911

Legs (set of 4)



Cast - Painted Black 850-126

Cast - Brushed Nickel 850-128

The instructions below apply to the steel leg, painted cast leg and the gold plated cast leg. It will be easier to attach the legs to the stove if the stove is tipped on its back (preferably on a soft surface to prevent scratching). Ensure to be extremely careful when tipping stove.

Important: Prior to installing the bottom hat shield, remove the 4 inch blanking plate. See below. This must be removed for combustion air to enter the appliance.

- 1) Remove the 4 bolts from underside of the base of the pedestal and discard. Also remove cover plate and put to the side.
- 2) Line up the heat shield with the bottom of the unit.
- 3) Start threading the bolt and washer (supplied with the bottom shield) for about 1/4 of the way through the leg with the washers being underneath the legs. Ensure that the legs are properly aligned with heat shield and tighten the bolts.
- 4) Level the stove by adjusting the levelling bolts in the bottom of each leg.




- 5) Reinstall cover plate.
- 6) Install logo plate onto heat shield by placing in 2 holes as shown in diagram.

If you are installing outside combustion air, bend the tabs out 90 degrees. Pipe fresh air into the bottom shield by using a minimum 4" duct pipe with a mesh grill at the outside termination. Attach the pipe to the 2 tabs with screws.

STEP-BY-STEP CHIMNEY AND CONNECTOR INSTALLATION

Note: These are a generic set of chimney installation instructions. Always follow the manufacturers own instructions explicitly. Verify the Minimum Recommended Heights for Woodstove Flue (Table 1 in the Installation section).

- 1) With your location already established, cut and frame the roof hole. It is recommended that no ceiling support member be cut for chimney and support box installation. If it is necessary to cut them, the members must be made structurally sound.
- 2) Install radiant shield and support from above.
- 3) Stack the insulated pipe onto your finish support to a minimum height of 3 feet above the roof penetration, or 2 feet above any point within 10 feet measured horizontally. There must be at least 3 feet of chimney above the roof level.



Note: Increasing the chimney height above this minimum level will sometimes help your unit to "breathe" better by allowing a greater draft to be created. This greater draft can decrease problems such as, difficult start-ups, back-smoking when door is open, and dirty glass. It might be sufficient to initially try with the minimum required height, and then if problems do arise add additional height at a later date.



- 4) Slide the roof flashing over your chimney and seal the flashing to the roof with roofing compound. Secure the flashing to your roof with nails or screws.
- 5) Place the storm collar over the flashing, sealing the joints with a silicone caulking.
- 6) Fasten the raincap with spark screens (if required) to the top of your chimney.
- 7) For optimum efficiency when installing into a masonry chimney, size accordingly, i.e. the 6" (152mm) flue dia. is 28.28 sq.in.

- 8) To complete your chimney installation, install the double wall connector pipe from the stove's flue collar to the chimney support device.

- 9) If you are using a horizontal connector, the chimney connector should be as high as possible while still maintaining the 18" (457mm) minimum distance from the horizontal connector to the ceiling.

10) NOTE: Residential Close Clearance and Alcove installations require a listed double wall connector from the stove collar to the ceiling level.

The diagrams below illustrate one way to install your unit into a standard ceiling or with a horizontal connector. Check with your dealer or installer for information on other options available to you.




Horizontal Installation

MASONRY CHIMNEY

Ensure that a masonry chimney meets the minimum standards of the National Fire Protection Association (NFPA) by having it inspected by a professional. Make sure there are no cracks, loose mortar or other signs of deterioration and blockage. Have the chimney cleaned before the stove is installed and operated. When connecting the stove through a combustible wall to a masonry chimney, special methods are needed.

When referencing installation or connection to masonry fireplaces or chimneys, the masonry construction must or shall be code complying.




MASONRY FIREPLACE

There are listed kits available to connect a stove to a masonry fireplace. The kit is an adapter that is installed at the location of the fireplace damper. The existing damper may have to be removed to allow installation.

This unit is designed to use either a 5.5" (140mm) or 6" (152mm) flue liner only within the confines of the masonry chimney as shown.

When referencing installation or connection to masonry fireplaces or chimneys, the masonry construction must or shall be code complying.




FACTORY BUILT CHIMNEY

When a metal prefabricated chimney is used, the manufacturer's installation instructions must be followed. You must also purchase and install the ceiling support package or wall pass-through and "T" section package, firestops (where needed), insulation shield, roof flashing, chimney cap, etc. Maintain proper clearance to the structure as recommended by the manufacturer. The chimney must be the required height above the roof or other obstructions for safety and proper draft operation.

COMBUSTIBLE WALL CHIMNEY CONNECTOR PASS-THROUGHS


Method A: 12" (304.8 mm) Clearance to Combustible Wall Member:

Using a minimum thickness 3.5" (89 mm) brick and a 5/8" (15.9 mm) minimum wall thickness clay liner, construct a wall pass-through. The clay liner must conform to ASTM C315 (Standard Specification for Clay Fire Linings) or its equivalent. Keep a minimum of 12" (304.8 mm) of brick masonry between the clay liner and wall combustibles. The clay liner shall run from the brick masonry outer surface to the inner surface of the chimney flue liner but not past the inner surface. Firmly grout or cement the clay liner in place to the chimney flue liner.




Method B: 9" (228.6 mm) Clearance to Combustible Wall Member:

Using a 6" (152.4 mm) inside diameter, listed, factory-built Solid-Pak chimney section with insulation of 1" (25.4 mm) or more, build a wall pass-through with a minimum 9" (228.6 mm) air space between the outer wall of the chimney length and wall combustibles. Use sheet metal supports fastened securely to wall surfaces on all sides, to maintain the 9" (228.6 mm) air space. When fastening supports to chimney length, do not penetrate the chimney liner (the inside wall of the Solid-Pak chimney). The inner end of the Solid-Pak chimney section shall be flush with the inside of the masonry chimney flue, and sealed with a non-water soluble refractory cement. Use this cement to also seal to the brick masonry penetration.




Method C: 6" (152.4 mm) Clearance to Combustible Wall Member:

Starting with a minimum 24 gage (.024" [.61 mm]) 6" (152.4 mm) metal chimney connector, and a minimum 24 gage ventilated wall thimble which has two air channels of 1" (25.4 mm) each, construct a wall pass-through. There shall be a minimum 6" (152.4 mm) separation area containing fiberglass insulation, from the outer surface of the wall thimble to wall combustibles. Support the wall thimble, and cover its opening with a 24-gage minimum sheet metal support. Maintain the 6" (152.4 mm) space. There should also be a support sized to fit and hold the metal chimney connector. See that the supports are fastened securely to wall surfaces on all sides. Make sure fasteners used to secure the metal chimney connector do not penetrate chimney flue liner.



Method D: 2" (50.8 mm) Clearance to Combustible Wall Member:

Start with a solid-pak listed factory built chimney section at least 12" (304 mm) long, with insulation of 1" (25.4 mm) or more, and an inside diameter of 8" (2 inches [51 mm] larger than the 6" [152.4 mm] chimney connector). Use this as a pass-through for a minimum 24-gage single wall steel chimney connector. Keep solid-pak section concentric with and spaced 1" (25.4 mm) off the chimney connector by way of sheet metal support plates at both ends of chimney section. Cover opening with and support chimney section on both sides with 24 gage minimum sheet metal supports. See that the supports are fastened securely to wall surfaces on all sides. Make sure fasteners used to secure chimney flue liner.



RECOMMENDED HEIGHTS FOR WOODSTOVE FLUE

Draft is the force which moves air from the appliance up through the chimney. The amount of draft in your chimney depends on the length of the chimney, local geography, nearby obstructions and other factors. Too much draft may cause excessive temperatures in the appliance and may cause damage. An uncontrollable burn or excessive temperature indicates excessive draft. Inadequate draft may cause back puffing into the room and plugging of the chimney. Inadequate draft will cause the appliance to leak smoke into the room through appliance and chimney connector joints. Ensure the heater is installed in areas that are not too close to neighbors or in valleys that would cause unhealthy air quality or nuisance conditions.

Simple rules on draft (refer to Table 1).

1) At sea level minimum height is 12' straight.

2) Add the following vertical height to compensate for:

45 deg. elbow = 1 ft.

90 deg. elbow = 2 ft.

"T" = 3 ft.

Each foot of horizontal run = 2 ft.

3) Add 4% overall for each 1000' above sea level.

Example: a)

1-1/2 ft. of horizontal run = 3 ft.

one "T" = 3 ft.

Total Addition (at sea level) = 6 ft.

Example: b)

One 90 deg. elbow = 2 ft.

2 ft. of horizontal run = 4 ft.

one "T" = 3 ft.

Total Addition (at sea level) = 9 ft.

| Recommended Flue Height | | |
|-------------------------|------------|------------|
| Elevation | Example a) | Example b) |
| 0' | 18' | 21' |
| 1000' | 18.72' | 21.84' |
| 2000' | 19.44' | 22.68' |
| 5000' | 21.60' | 25.20' |
| 8000' | 23.76' | 27.72' |

| MINIMUM RECOMMENDED FLUE HEIGHTS IN FEET (Measured from the top of the unit) | | | | | | | |
|---|-------------|---------|---------|---------|---------|---------|---------|
| ELEVATION (FT) ABOVE SEA LEVEL | # OF ELBOWS | | | | | | |
| | 0 | 2 x 15° | 4 x 15° | 2 x 30° | 4 x 30° | 2 x 45° | 4 x 45° |
| 0-1000 | 12.0 | 13.0 | 14.0 | 15.0 | 18.0 | 16.0 | 20.0 |
| 1000-2000 | 12.5 | 13.5 | 14.5 | 15.5 | 19.0 | 16.5 | 21.0 |
| 2000-3000 | 13.0 | 14.0 | 15.0 | 16.0 | 19.5 | 17.0 | 21.5 |
| 3000-4000 | 13.5 | 14.5 | 15.5 | 17.0 | 20.0 | 18.0 | 22.5 |
| 4000-5000 | 14.0 | 15.0 | 16.0 | 17.5 | 21.0 | 18.5 | 23.0 |
| 5000-6000 | 14.5 | 15.5 | 17.0 | 18.0 | 21.5 | 19.0 | 24.0 |
| 6000-7000 | 15.0 | 16.0 | 17.5 | 18.5 | 22.5 | 20.0 | 25.0 |
| 7000-8000 | 15.5 | 16.5 | 18.0 | 19.0 | 23.0 | 20.5 | 25.5 |
| 8000-9000 | 16.0 | 17.0 | 18.5 | 20.0 | 24.0 | 21.0 | 26.5 |
| 9000-10000 | 16.5 | 17.5 | 19.0 | 20.5 | 24.5 | 22.0 | 27.0 |
| NOTE: No more than two offsets (four elbows) allowed. Two 45° elbows equal one 90° elbow. | | | | | | | |

MOBILE HOME INSTALLATION

Once you have properly marked the position of your unit and the floor protection as outlined in the Residential Installation items #1 through #8, a supply of fresh air has to be supplied to your unit. Cut a minimum 4" (102mm) diameter hole through your floor protector and the floor directly under your pedestal base to the outside. Use 4" (102mm) duct pipe with a mesh grill to pipe fresh air into the pedestal area. Block off the hole in the back of the pedestal with the square plate and the two 1/2" screws provided.


Place your unit in position and secure it to the floor using two lag bolts 3/8" (10mm) x 3-1/2" (89mm) through the two holes inside the pedestal base. It is important to maintain the structural integrity of the Mobile Home floor, walls and roof when installing your unit.

For Mobile Home units installed in the U.S. the unit must be grounded using a #8 ground wire with approved termination and star washer.

CAUTION: At no time use unlabelled parts, or substitute parts made for another chimney system.

Install as per chimney manufacturer's installation instructions.

WARNING: Operate only with door fully closed - open feed door to feed fire only.



In addition to standard installation instructions the following requirements are mandatory for installation in a mobile home.

- 1) The stove must be permanently bolted to the floor of the Mobile Home using the floor screws provided.
- 2) The stove must have a permanent outside air source for combustion.
- 3) The stove must be electrically grounded to the steel chassis of the Mobile Home.
- 4) A listed double-wall connector chimney system, roof thimble, spark arrestor and roof flashing kit suitable for use in Mobile Homes must be used.
- 5) If the chimney exits the Mobile Home at a location other than through the roof, and exits at a point 7ft. (2130mm) or less above the ground level on which the Mobile Home is positioned a guard or method of enclosing the chimney shall be fitted at the point of exit for a height up to 7ft. (2130mm).
- 6) The chimney shall be attached directly to the room heater and shall extend at least 3 ft. (914mm) above the part of the roof through which it passes. The top of the chimney should project at least 2ft. (610mm) above the highest elevation of any part of the Mobile Home within 10 ft. (3048mm) of the chimney.
- 7) The chimney system shall comply with Local Requirements.
- 8) Any openings in a chimney guard where required must not permit the entrance of 3/4" (19mm) diameter rod.
- 9) **CAUTION: THE STRUCTURAL INTEGRITY OF THE MOBILE HOME ROOF, FLOOR, WALLS AND CEILING MUST BE MAINTAINED.**
- 10) Check any other local building code as other local codes may apply.
- 11) **WARNING: DO NOT INSTALL IN A SLEEPING ROOM OF A MOBILE HOME.**
- 12) Use silicone to create an effective vapour barrier at the location where the chimney or other component penetrates to the exterior of the structure.

LISTED COMPONENTS FOR MOBILE HOME INSTALLATION

The Regency F2400M and S2400M Freestanding pedestal units are approved for installation in a Mobile Home if one of the following pipe systems is used.

U.S. Installation*

METALBESTOS SSII

| Qty. | Part # | Description |
|------|--------|----------------|
| 1 | 6DS-VK | Connector Kit |
| 1 | 6TMH | Shield/Support |
| 1 | 6TAF-6 | Flashing |
| 1 | 6T-36 | Chimney Length |
| 1 | 6T-18 | Chimney Length |
| 1 | 6T-CT | Rain Cap |

PRO-JET 3103

| Qty. | Part # | Description |
|------|---------|------------------|
| 1 | PV06-TK | Connector |
| 1 | CSB | Shield/Support |
| 1 | RRS | Radiation Shield |
| 1 | LFR03 | Flashing |
| 1 | SL3 | Chimney Length |
| 1 | SL1 | Chimney Length |
| 1 | RCSA | Rain Cap |

SECURITY ASHT

| Qty. | Part # | Description |
|------|---------|----------------|
| 1 | DL42A-6 | Connector Kit |
| 1 | 6SS | Shield/Support |
| 1 | 6FAMH | Flashing |
| 1 | 6L3 | Chimney Length |
| 1 | 6L1 | Chimney Length |
| 1 | CPE | Rain Cap |

SECURITY S2100

| Qty. | Part # | Description |
|------|---------|----------------|
| 1 | DL42A-6 | Connector Kit |
| 1 | 6XSF | Support |
| 1 | 6XFA | Flashing |
| 1 | 6XL3 | Chimney Length |
| 1 | 6XL18 | Chimney Length |
| 1 | 6XCPE | Rain Cap |

METAL-FAB TEMP/GUARD 2100

| Qty. | Part # | Description |
|------|--------|----------------|
| 1 | 6DWBK | Connector |
| 1 | 6TGRS | Roof Support |
| 1 | 6TGG36 | Chimney Length |
| 1 | 6TGG12 | Chimney Length |
| 1 | 6TGF | Flashing |
| 1 | 6TGC | Rain Cap |

AMERI-TEC HS

| Qty. | Part # | Description |
|------|----------|----------------------------|
| 1 | 6DCC | Connector |
| 1 | 6HSRS-12 | Roof Support (6PLRS-12-BK) |
| 1 | 6F | Flashing |
| 1 | 6HS-36 | Chimney Length |
| 1 | 6HS-18 | Chimney Length |
| 1 | 6HS-RCS | Rain Cap (6PL-MPC) |

SIMPSON DURA-PLUS

| Qty. | Part # | Description |
|------|------------|-----------------|
| 1 | 6DVL8693 | Connector Kit |
| 1 | 6DP-MH9096 | Mobile Home Kit |

ICC EXCEL 2100

| Qty. | Part # | Description |
|------|----------|---|
| 1 | 6CL48 | 48" Chimney length (also in 12", 18", 24" lengths.) |
| 1 | 6RC | Rain Cap |
| 1 | 6RCS | Spark Screen (for rain cap) |
| 1 | 6RDS/SQS | Round/Square support box |
| 1 | 6VF | Flashing |
| 1 | 6UBA | "Ultrablack" Close Clearance Connector |

Canadian Installations*

SECURITY S2100 (see above for details)

ICC EXCEL 2100 (see above for details)

SELKIRK SENTINAL CF

*The use of alternate pitch flashings, support box extensions, additional chimney lengths, and additional chimney bracing, may be used on each of the previously listed systems. These parts though must be from the same system as listed, and must be a similar and/or complimentary part.

CAUTION: At no time use unlabelled parts, or substitute parts made for another chimney system.

Install as per chimney manufacturer's installation instructions.

FLUE BAFFLE & SECONDARY AIR TUBE INSTALLATION

The flue baffle system located in the upper area of the firebox is removable to make cleaning your chimney system easier. The baffles must be installed prior to your first fire. **Smoke spillage and draft problems may occur if the baffles are improperly positioned.** Check the position of the baffles on a regular basis as they can be dislodged if too much fuel is forced into the firebox.


Freestanding Stove F2400M

The unit arrives with the 2 baffles on the floor of the firebox.

- 1) If all 4 air tubes are installed continue on to Step 2), if not, follow the instructions below. Install the air tube into the holes in the side channels. The notch goes on the right hand side with the air holes facing toward the door.


Slide the tube into the left hand side, as far as possible and then bring it back into the hole on the right hand side until it locks into position. If the tube will not slide in easily, simply use a pair of vise grips or pliers and tap it into place with a hammer. A tighter fit will ensure the tube will not move when the unit is burning.

- 2) Slide the left baffle over the air tubes from the front and then push it to the back.




Side View

- 3) Tilt the left baffle up on top of the side channel and it will leave enough room to position the right baffle in the same manner as Step 1) above. Then reposition the left baffle flat on the air tubes.



Front View

- 4) Important: push both baffles so they are tight against the side walls.




Front View


Note: When getting the chimney cleaned, push the baffles forward toward the front of the stove, this should leave sufficient access to the flue. If it is not enough space then remove the middle air tube (reverse the procedure in step 1) above), and baffle and then replace everything when cleaning is completed.

STAINLESS STEEL SMOKE DEFLECTOR ADJUSTMENT / REPLACEMENT

The stainless smoke deflector is located in the upper front area of the firebox. The deflector is held in place with 2 bolts. Prior to the first fire, ensure deflector is seated properly and secured with 2 **hand tightened** bolts.



Smoke deflector



Smoke deflector installed with 2 bolts.

Note: *This is a view from the back of the unit through the top.*

To replace the deflector, loosen off both bolts and slide deflector upward and out. Install new deflector and hand tighten bolts. Ensure positive location of the deflector prior to hand tightening.

WARNING: Operation of the unit with out proper installation of smoke deflector will void warranty.




Ensure deflector is seated so bolts are situated at the top of the keyhole before tightening. Hand tighten bolts only.

BRICK INSTALLATION


Firebrick is included to extend the life of your stove and radiate heat more evenly. Check to see that all firebricks are in their correct positions and have not become misaligned during shipping.

The "AD" brick in the drawings below is the brick covering the Ash Dump hole that is used when the Ash Drawer Kit is installed.




CLASSIC DOOR HANDLE

Attach spring handle by rotating counter clockwise onto rod. Ensure that the rod fits into the entire length of the spring handle (refer to the Diagram below).




The cool to touch door handle is designed to be inserted from the bottom up and slide off when not held in place. Once in position, the door can be opened. After use, store the door handle on the storage hook located on the left side of the faceplate



WARNING: FAILURE TO USE REMOVABLE HANDLE AS PER INSTRUCTIONS MAY CAUSE SERIOUS BURNS.

GLASS INSTALLATION

Remove the door from the stove and remove the glass retainer. Position the glass in the door, make sure that the glass gasketing will properly seal your unit, and replace the retainer, it should rest on the gasket not the glass. Tighten securely, but do not wrench down on the glass as this may cause the glass to break. Be careful of the edge clearances, maintain glass edge clearances.




STEP-BY-STEP OPTIONAL ACCESSORIES INSTALLATION

The pieces listed below can be purchased and installed during the initial installation or added on later.

Pedestal Ash Drawer Kit (850-100)

- 1) Remove the bricks from the floor of the firebox.
- 2) If using ashdrawer, discard cover plate.
- 3) Remove the ash dump cover plates (one inside the firebox and one on the underside of the firebox) by removing the two nuts and bolts holding the 2 plates together from inside the firebox.
- 4) Push the ash plug into the hole inside the firebox and replace all the bricks except for the brick over the ash plug (refer to the brick diagram in the Brick Installation section).
- 5) Place the ash drawer lid inside the pedestal, and the ash plug tool beside the lid, then slide the ash drawer inside so it sits on top of the lid.




Refer to the Ash Drawer Operating Guidelines in the Operating Instructions section.

Bottom Shield Ash Drawer Kit (850-101)


- 1) Remove the bricks from the floor of the firebox.
- 2) Remove and discard the cover plate by removing the two screws on the front of the Bottom Shield.
- 3) Remove the ash dump cover plates (one inside the firebox and one on the underside of the firebox) by removing the two nuts and bolts holding the 2 plates together from inside the firebox.

CONTEMPORARY DOOR HANDLE




- 4) Push the ash plug into the hole inside the firebox and replace all the bricks except for the brick over the ash plug (see brick diagram in the Brick Installation section).
- 5) Place the ash plug tool beside the lid, then slide the ash drawer inside.

Refer to Ash Drawer Operating Guidelines in the Operating Instructions section.



SCREEN DOOR


Hook screen to the inside on the right side of the firebox door opening. Lock in place by turning handle.



Hooks Handle Lock

Back Side of Screen Shown

NOTE: The handle must be positioned at 10 o'clock when closed to avoid the handle from getting hot and to ensure the screen stays in place.






Handle at 10 o'clock position.

Blower/Fan (846-515)

- 1) Remove the two screws from the top of the fan housing.
- 2) Slide the fan up into the rear heat shield.
- 3) After aligning holes, secure the fan to the rear heat shield using the two screws removed earlier.

CAUTION: The connection cord should not be in contact with any hot surfaces. Do not route cord under or in front of unit.

Read the Fan Operation instructions before using.



Blower/Fan Wiring Diagram

CAUTION: Label all wires prior to disconnection when servicing controls. Wiring errors can cause improper and dangerous operation.

WARNING: Electrical Grounding Instructions
This appliance is equipped with a three pronged (grounding) plug for your protection against shock hazard and should be plugged directly into a properly grounded three-prong receptacle. Do not cut or remove the grounding prong from this plug.

SEASONED WOOD

Whether you burn wood in a fireplace, stove or insert, good quality firewood is the key to convenience, efficiency and safety. Wet wood and pieces that are not the right size and shape for your wood burner can be frustrating, burn inefficiently and deposit creosote that can fuel a dangerous chimney fire. Good planning, seasoning and storage of the firewood supply are essential to successful wood burning.

- Stack the wood in separate rows in an open location where the summer sun can warm it and breezes can carry away the moisture. Do not stack unseasoned wood tightly in an unvented storage area.
- Do not allow firewood to lie on the ground for more than a couple of days before stacking. Mould and rot can set in quickly.
- Stack the wood up off the ground on poles, lumber rails or pallets.
- The top of the pile can be covered to keep off rain, but do not cover the sides.

Softer woods like pine, spruce and poplar/aspen that is cut, split and stacked properly in the early spring maybe be ready for burning in the fall. Extremely hard woods like oak and maple, and large pieces of firewood, may take a minimum of a full year to dry enough. Drying may also take longer in damp climates

There are a few ways to tell if wood is dry enough to burn efficiently. Use as many indicators as possible to judge the dryness of the firewood your are considering. Here are ways to judge firewood moisture.

- Using a moisture meter, select the species of fuel and then penetrate the pins into a split piece. Ideal moisture and seasoned firewood should be less than 20% moisture content.
- Checks or cracks in the end grain can be an indication of dryness, but may not be a reliable indicator. Some wet wood has checks and some dry wood has no checks.
- The wood tends to darken from white or cream colour to grey or yellow as it dries.
- Two dry pieces banged together sound hollow; wet pieces sound solid and dull.
- Dry wood weighs much less than wet wood.
- Split a piece of wood. If the exposed surface feels damp, the wood is too wet to burn.

OPERATING INSTRUCTIONS

With your unit now correctly installed and safety inspected by your local authority, you are now ready to start a fire. Before establishing your first fire, it is important that you fully understand the operation of your draft control.

WARNING


Fireplace Stoves equipped with doors should be operated only with doors fully open or doors fully closed. If doors are left partly open, gas and flame may be drawn out of the fireplace stove opening, creating risks from both fire and smoke.

When operated with doors open the manufacturer supplied screen must be used.

DRAFT CONTROL

Both the primary and air wash drafts are controlled by the control rod located on the left side of the unit (when facing the unit). To increase your draft - pull open, and to decrease - push closed. All units have a secondary draft system that continually allows combustion air to the induction ports at the top of the firebox, just below the flue baffle.

Important: If you are using room air for combustion, make sure that the back cover plate at the rear of the pedestal is not installed. The cover plate must be installed on the unit if your stove is located in a mobile home or if using outside air from the bottom.



WARNING: To build a fire in ignorance or to disregard the information contained in this section can cause serious permanent damage to the unit and void your warranty!!



How to Light & Maintain a Wood Stove Fire

FIRST FIRE

When your installation is completed and inspected you are ready for your first fire.

- 1) Open control fully.
- 2) Open firebox door and build a small fire using paper and dry kindling on the firebrick hearth. Secure door on the firebox and wait a few minutes for a good updraft in the flue to establish the fire. (Leaving the door slightly open will help your fire start more rapidly.)

CAUTION: Never leave unit unattended if door is left open. This procedure is for fire start-up only, as unit may overheat if door is left open for too long.

- 3) With the draft still in the fully open position add two or three seasoned logs to your fire. Form a trench in the ash bed to allow air to reach the rear of the firebox prior to closing the door.
- 4) After about 45 minutes, when your wood has begun to burn strongly, adjust your draft control down to keep the fire at a moderate level.

WARNING: Never build a roaring fire in a cold stove. Always warm your stove up slowly!

- 5) Once a bed of coals has been established on the firebrick hearth, you may adjust the draft control to a low setting to operate the unit at its most efficient mode.
- 6) During the first few fires, keep the combustion rate at a moderate level and avoid a large fire. Only after 5 or 6 such fires can you operate the stove at its maximum setting, and only after the metal has been warmed.
- 7) For the first few days, the stove will give off an odour from the paint. This is to be expected as the high temperature paint becomes seasoned. Windows and/or doors should be left open to provide adequate ventilation while this temporary condition exists. Burning the stove at a very high temperature the first few times may damage the paint. Burn fires at a moderate level the first few days.
- 8) Do not place anything on the stove top during the curing process. This may result in damage to your paint finish.
- 9) During the first few days it may be more difficult to start the fire. As you dry out your firebrick and your masonry flue, your draft will increase.
- 10) For those units installed at higher elevations or into sub-standard masonry fireplaces, drafting problems may occur. Consult an experienced dealer or mason on methods of increasing your draft.

11) Some cracking and popping noises may be experienced during the heating up process. These noises will be minimal when your unit reaches temperature.

12) Before opening your door to reload, open draft fully for approximately 10 to 15 seconds until fire has been re-established. This will minimize any smoking.

13) All fuel burning appliances consume oxygen during operation. It is important that you supply a source of fresh air to your unit while burning. A slightly opened window is sufficient for the purpose. If you also have a fireplace in your home, a downdraft may be created by your Regency Stove causing a draft down your chimney. If this occurs, slightly open a window near your unit.

CAUTION: If the body of your unit, flue baffle or any part of the chimney connector starts to glow, you are over firing. Stop loading fuel immediately and close the draft control until the glow has completely subsided.

14) Green or wet wood is not recommended for your unit. If you must add wet or green fuel, open the draft control fully until all moisture has been dispersed by the intense fire. Once all moisture has been removed, the draft control may be adjusted to maintain the fire.

15) If you have been burning your stove on a low draft, use caution when opening the door. After opening the damper, open the door a crack, and allow the fire to adjust before fully opening the door.

16) The controls of your unit or the air supply passages should not be altered to increase firing for any reason.

17) If you burn the unit too slowly or at too low a setting your unit will not be operating as efficiently as it can. An easy rule of thumb says that if your glass is clean, then your flue is clean and your exhaust is clean. Burn the stove hot enough to keep your glass clean and you won't need to clean your flue as often.

CAUTION: Do not use chemical or flammable fluids to start the fire.

CAUTION: Do not burn garbage or flammable fluids such as gasoline, naphtha or engine oil.

FAN OPERATION

Automatic

To operate the fan automatically, push the bottom switch on the side of the fan housing to "AUTO" and the top switch to either "HIGH" or "LOW" for fan speed.

This will allow the fan to turn on as the stove has come up to operating temperature. It will also shut the fan system off after the fire has gone out and the unit cooled to below a useful heat output range.

Manual

To manually operate the fan system push the bottom switch to "MAN" and the top switch to either "HIGH" or "LOW". This will bypass the sensing device and allow full control of the fan.

Switching from "AUTO" to "MAN" or "HIGH" to "LOW" may be done anytime.

ASH DISPOSAL


During constant use, ashes should be removed every few days. The Ash Drawer option features a convenient ash dump for easy removal of ash, refer to Modular Installation Options section.

Safety Precautions

- 1) Do not allow ashes to build up to the loading doors! Only remove ashes when the fire has died down. Even then, expect to find a few hot embers.
- 2) Please take care to prevent the build-up of ash around the start-up air housing located inside the stove box, under the loading door lip.
- 3) Never start a fire if the ash plug and ash drawer are not in place. This will cause over firing which can cause excessive warping of the stove. Evidence of over firing can void the warranty on your stove.
- 4) The firebricks are brittle and can be damaged if the plug is replaced carelessly or pieces that are too large are forced through the hole.

Ash Drawer Operating Guideline


- 1) Only clean ashes out of the stove when the unit has cooled down. Remove the plug by lifting on the handle using the tool provided. The plug may still be warm, use caution. Push the ashes down the hole into the ash drawer, the large pieces can be left in the firebox and burned during the next fire or removed through the door opening.



- 2) Always leave 1/2 to 1 inch of ash in the bottom of the firebox. This helps in easier starting and a more uniform burn of your fire. Replace ash plug when ashes have been removed.


3) Pedestal Units:

To remove the drawer, lift slightly and slide it out. When the drawer is completely out, slide the cover plate over the ash drawer and carry away.



Bottom Shield (with Legs) Units:

To remove the drawer, lift slightly and slide it out, and carry it away.



- 4) When emptying the ash drawer, make sure the ashes are cold. Ashes should be placed in a metal container with a tight fitting lid. The closed container of ashes should be placed on a non-combustible floor or on the ground, well away from all combustible materials, pending final disposal. If the ashes are disposed of by burial in soil or otherwise locally dispersed, they should be retained in the closed container until all cinders have thoroughly cooled. Other waste should not be placed in the ash container.
- 5) Before putting the ash drawer back into place, make sure the ash plug is back in place.

Pedestal Units: make sure the cover lid is off.

SAFETY GUIDELINES AND WARNINGS

DO NOT OVERFIRE THIS HEATER

Attempts to achieve heat output rates that exceed heater design specifications can result in permanent damage to the heater.

- 1) Never use gasoline, gasoline type lantern fuels, kerosene, charcoal lighter fuel, or similar liquids to start or 'freshen up' a fire in your heater. Keep all such liquids well away from the heater while it is in use.
- 2) Keep the door closed during operation and maintain all seals in good condition.
- 3) Do not burn any quantities of paper, garbage, and never burn flammable fluids such as gasoline, naphtha or engine oil in your stove.
- 4) If you have smoke detectors, prevent smoke spillage as this may set off a false alarm.
- 5) Do not overfire heater. If the chimney connector, flue baffle or the stove top begin to glow, you are over firing. Stop adding fuel and close the

draft control. Over firing can cause extensive damage to your stove including warpage and premature steel corrosion. Over firing will void your warranty.

- 6) Do not permit creosote or soot build-up in the chimney system. Check and clean chimney at regular intervals. Failure to do so can result in a serious chimney fire.
- 7) Your Regency stove can be very hot. You may be seriously burned if you touch the stove while it is operating, keep children, clothing and furniture away. Warn children of the burn hazard.
- 8) The stove consumes air while operating, provide adequate ventilation with an air duct or open a window while the stove is in use.
- 9) Do not connect this unit to a chimney flue serving another appliance.
- 10) Do not use grates or andirons or other methods for supporting fuel. Burn directly on the bricks.
- 11) Open the draft control fully for 10 to 15 seconds prior to slowly opening the door when refuelling the fire.
- 12) Do not connect your unit to any air distribution duct.
- 13) Your woodstove should burn dry, standard firewood only. The use of cut lumber, plywood, "mill ends", etc. is not allowed as this fuel can easily overheat your woodstove. Evidence of excessive overheating will void your warranty. As well, a large portion of sawmill waste is chemically treated lumber, which is illegal to burn in many areas. Salt drift wood and chemically treated fire logs also must not be burned in your woodstoves.
- 14) Do not store any fuel closer than 2 feet from your unit. Do not place wood, paper, furniture, drapes or other combustibles near the appliance.

15) WARNING: Do not operate without either the Ash Plug properly seated or the Ash Dump Plates screwed in place, excessive temperatures will result.

16) Do not operate with broken glazing.

CAUTION: Warranty will be void if any make shift compromises are used during installation.

CAUTION: Do not connect to, or use in conjunction with, any air distribution duct work, unless specifically approved for such installations.

CAUTION: Poor performance, smoke spillage, incorrect chimney location, can be possible effects of room air starvation, icing and exhaust fans. Ensure adequate ventilation and correct chimney location.

CAUTION: Certain fuels, such as charcoal and wet wood, can create the possibility of generating carbon monoxide (CO). CO is a dangerous by product that is odourless and can cause serious injury

MAINTENANCE

It is very important to carefully maintain your stove, including burning seasoned wood and maintaining a clean stove and chimney system. Have the chimney cleaned before the burning season and as necessary during the season, as creosote deposits may build up rapidly. Moving parts of your stove require no lubrication. The integrity of all heater parts including baffle plates, cast iron liners, fire bricks, air tubes, air bars, door rope seals, and door glass is imperative for the correct operation and longevity of your Regency Wood heater. They should be inspected on a regular basis and replaced if they show any signs of undue wear or damage. Failure of any of these components can damage the heater and void warranty.

CREOSOTE

When wood is burned slowly, it produces tar and other organic vapours, which when combined with moisture, form creosote. The creosote vapours condense in the relatively cool chimney flue of a slow burning fire. As a result, creosote residue accumulates on the flue lining. When ignited, this creosote can result in an extremely hot fire.

WARNING: Things to remember in case of a chimney fire:

1. Close all draft and damper controls.
2. CALL THE FIRE DEPARTMENT.

Ways to Prevent and Keep Unit Free of Creosote

- 1) Burn stove with the draft control wide open for about 10-15 minutes every morning during burning season.
- 2) Burn stove with draft control wide open for about 10 - 15 minutes every time you apply fresh wood. This allows the wood to achieve the charcoal stage faster and burns up any unburned gas vapours which might otherwise be deposited within the system.
- 3) **Only burn seasoned wood!** Avoid burning wet or green wood. Seasoned wood has been dried at least one year.
- 4) A small hot fire is preferable to a large smouldering one that can deposit creosote within the system.

- 5) The chimney and chimney connector should be inspected at least once every two months during the heating season to determine if a creosote buildup has occurred.
- 6) **Have chimney system and unit cleaned by competent chimney sweeps twice a year during the first year of use and at least once a year thereafter or when a significant layer of creosote has accumulated (3 mm/1/8" or more) it should be removed to reduce the risk of a chimney fire.**

MAINTENANCE OF NICKEL-PLATED DOORS

The nickel electroplated finish on the door requires little maintenance, and needs only to be cleaned with a damp cloth. DO NOT use abrasive materials or chemical cleaners, as they may harm the finish and void the warranty.

GLASS MAINTENANCE


Your Regency stove is supplied with 5 mm Neoceram ceramic glass (Part #846-302) that will withstand the highest heat that your unit will produce. In the event that you break your glass by impact, purchase your replacement from an authorized Regency dealer only, and follow our step-by-step instructions for replacement (refer to Glass Installation section).

Allow the stove to cool down before cleaning the glass, do not clean the glass when it is hot. Do not use abrasive cleaners.

WARNING: Do not abuse glass door such as striking or slamming shut.

LATCH ADJUSTMENT

The door latch may require adjustment as the door gasket material compresses after a few fires. Removal of the spacer washer, shown in the diagram below, will allow the latch to be moved closer to the door frame, causing a tighter seal. Remove and replace the nuts, washer and spacer as shown.



DOOR GASKET

If the door gasket requires replacement 7/8" diameter material must be used. The kit (Part #846-570) includes adhesive to secure the gasket to the door. A proper high temperature gasket adhesive is required. See your Regency Dealer.

WOOD STORAGE

Store wood under cover, such as in a shed, or covered with a tarp, plastic, tar paper, sheets of scrap plywood, etc., as uncovered wood can absorb water from rain or snow, delaying the seasoning process.




Cleaning & Maintaining Your Wood Stove

F2400M STOVE MAIN ASSEMBLY W/CLASSIC DOOR

| Part# | Description | Part# | Description |
|----------------|-------------------------------------|---------------|--|
| 1) 850-141 | Door Assy - Black | 846-515 | Complete Fan/Blower Assy (120 V) |
| 850-143 | Door Assy - Nickel Accent | 25) 910-684 | Power Cord (120 V) |
| 3) 846-302 | Glass - Replacement - F2400M | 27) 910-142 | Thermodisc - Fan Auto ON/OFF |
| 4) 936-243 | 7/8" Adhesive Tape Gasket | 28) 910-138 | Manual/Auto Switch (2-way) |
| 5) 846-920 | Glass Retainer Clips/Screws (8/set) | 29) 910-140 | Fan Speed Switch HI/OFF/LOW (3-way) |
| 6) * | Screw - 1/4 - 20 x 3/8" | 30) 910-157/P | Fan/Blower Motor (120 V) |
| 7) 948-170/P | Small Glass Retainer F2400M | 36) 033-953 | Air Tube - 3/4" F2400M (Qty: 4) (each) |
| 8) 020-363 | Left Side Heat Shield | 37) 020-957 | Baffle (set) F2400M |
| 020-364 | Right Side Heat Shield | 40) 815-557 | Rear Air Deflector |
| 9) 846-973 | Door Handle Assembly | 41) 850-105 | Airmate - Medium |
| 12) 820-375 | Ash Hole Cover Plate | 42) 846-101 | Screen Door |
| 13) * | Bolt 1/4 - 20 x 1/2 Hex Head | 43) 820-482 | Smoke Deflector |
| 14) 820-376 | Retainer Plate - Ash Dump - Top | | |
| 15) * | Nut - 1/4 - 20 Hex | 918-154 | Manual |
| 16) 846-570 | 7/8" Door Gasket Repair Kit | | |
| 17) 948-079 bn | Spring Hinge Cap Nickel (each) | | |
| 19) 948-135 | Spring Handle - Large Nickel | | |
| 20) 948-136 | Spring Handle - Small Nickel | | |


*Not available as a replacement part.



F2400M STOVE MAIN ASSEMBLY W/CONTEMPORARY DOOR

| Part# | Description | Part# | Description |
|--------------|-------------------------------------|---------------|--|
| 1) 850-161 | Door Assy - Contemporary | 846-515 | Complete Fan/Blower Assy (120 V) |
| 3) 846-302 | Glass - Replacement - F2400M | 25) 910-684 | Power Cord (120 V) |
| 4) 936-243 | 7/8" Adhesive Tape Gasket | 27) 910-142 | Thermodisc - Fan Auto ON/OFF |
| 5) 846-920 | Glass Retainer Clips/Screws (8/set) | 28) 910-138 | Manual/Auto Switch (2-way) |
| 6) * | Screw - 1/4 - 20 x 3/8" | 29) 910-140 | Fan Speed Switch HI/OFF/LOW (3-way) |
| 7) 948-170/P | Small Glass Retainer F2400M | 30) 910-157/P | Fan/Blower Motor (120 V) |
| 8) 020-363 | Left Side Heat Shield | 36) 033-953 | Air Tube - 3/4" F2400M (Qty: 4) (each) |
| 8) 020-364 | Right Side Heat Shield | 37) 020-957 | Baffle (set) F2400M |
| 9) 846-975 | Door Handle Assembly | 40) 815-557 | Rear Air Deflector |
| 12) 820-375 | Ash Hole Cover Plate | 41) 850-105 | Airmate - Medium |
| 13) * | Bolt 1/4 - 20 x 1/2 Hex Head | 42) 846-101 | Screen Door |
| 14) 820-376 | Retainer Plate - Ash Dump - Top | 43) 820-482 | Smoke Deflector |
| 15) * | Nut - 1/4 - 20 Hex | | |
| 16) 846-570 | 7/8" Door Gasket Repair Kit | 918-154 | Manual |
| 17) 948-082 | Hinge Cap Black (each) | | |
| 19) 156-241 | Cast Handle | | |
| 20) 948-144 | Small Spring Handle Black | | |


*Not available as a replacement part.



S2400M STEP STOVE MAIN ASSEMBLY W/CLASSIC DOOR

| Part# | Description | Part# | Description |
|----------------|-------------------------------------|---------------|--|
| 1) 850-141 | Door Assy - Black | 846-515 | Complete Fan/Blower Assy (120 V) |
| 850-143 | Door Assy - Nickel Accent | 25) 910-684 | Power Cord (120 V) |
| 3) 846-302 | Glass - Replacement - S2400M | 27) 910-142 | Thermodisc Fan Auto ON/OFF |
| 4) 936-243 | 7/8" Adhesive Tape Gasket | 28) 910-138 | Manual/Auto Switch (2-way) |
| 5) 846-920 | Glass Retainer Clips/Screws (8/set) | 29) 910-140 | Fan Speed Switch HI/OFF/LOW (3-way) |
| 6) * | Screw - 1/4 - 20 x 3/8" | 30) 910-157/P | Fan/Blower Motor (120 V) |
| 7) 948-170/P | Small Glass Retainer - S2400M | 36) 033-953 | Air Tube - 3/4" S2400M (Qty: 4) (each) |
| 8) 010-001 | Left Side Heat Shield | 37) 020-957 | Baffle (set) S2400M |
| 010-002 | Right Side Heat Shield | 42) 846-101 | Screen Door |
| 9) 846-973 | Door Handle Assembly | 919-542 | Manual |
| 16) 846-570 | 7/8" Door Gasket Repair Kit | | |
| 17) 948-079 BN | Hinge Cap Nickel (each) | | |
| 19) 948-135 | Spring Handle - Large Nickel | | |
| 20) 948-136 | Spring Handle - Small Nickel | | |


*Not available as a replacement part.



S2400M STEP STOVE MAIN ASSEMBLY W/CONTEMPORARY DOOR

| Part# | Description | Part# | Description |
|--------------|-------------------------------------|---------------|--|
| 1) 850-161 | Door Assy | 846-515 | Complete Fan/Blower Assy (120 V) |
| 3) 846-302 | Glass - Replacement - S2400M | 25) 910-684 | Power Cord (120 V) |
| 4) 936-243 | 7/8" Adhesive Tape Gasket | 27) 910-142 | Thermodisc Fan Auto ON/OFF |
| 5) 846-920 | Glass Retainer Clips /Screws(8/set) | 28) 910-138 | Manual/Auto Switch (2-way) |
| 6) * | Screw - 1/4 - 20 x 3/8" | 29) 910-140 | Fan Speed Switch HI/OFF/LOW (3-way) |
| 7) 948-170/P | Small Glass Retainer - S2400M | 30) 910-157/P | Fan/Blower Motor (120 V) |
| 8) 010-001 | Left Side Heat Shield | 36) 033-953 | Air Tube - 3/4" S2400M (Qty: 4) (each) |
| 010-002 | Right Side Heat Shield | 37) 020-957 | Baffle (set) S2400M |
| 9) 846-975 | Door Handle Assembly | | |
| 16) 846-570 | 7/8" Door Gasket Repair Kit | 919-542 | Manual |
| 17) 846-918 | Hinge Caps - Gold (2/set) | | |
| 948-082 | Hinge Cap Black (each) | | |
| 19) 156-241 | Cast Handle | | |
| 20) 948-144 | Small Spring Handle Black | | |

*Not available as a replacement part.




PEDESTAL, BOTTOM SHIELD & LEG OPTIONS


| Part# | Description |
|--------------|-----------------------------|
| 48) 020-925 | Pedestal - Medium |
| 49) 904-257 | Large Magnet Catch |
| 50) * | Knockout - Pedestal |
| 850-100 | Ashdrawer Kit - Pedestal |
| 45) * | Ashdrawer - Pedestal |
| 46) * | Ashdrawer Lid Assy |
| 58) 942-110 | Ash Plug |
| 59) 820-249 | Ash Plug Tool Handle |
| 56) 020-911 | Bottom Shield - Medium |
| 57) * | Blanking Plate - Btm Shield |
| 850-101 | Ashdrawer Kit - Btm Shield |
| 55) * | Ashdrawer - Bottom Shield |
| 58) 942-110 | Ash Plug |
| 59) 820-249 | Ash Plug Tool Handle |
| 140) 850-126 | Legs - Cast Black |
| 850-128 | Legs - Cast Brush Nickel |
| 948-223 | Regency Logo - Nickel |
| 919-542 | Manual |

*Not available as a replacement part.

INSTALL EITHER "BOTTOM SHIELD (OPTION)" OR "PEDESTAL (OPTION)"



INSTALL EITHER BLANK PLATE
OR ASH DRAWER




FIREBRICK

NOTE: This kit contains one spare brick in case of breakage.

Description

- 70) Brick - Regular Full Size: 1-1/4" x 4-1/2" x 9"
- 72) Brick Partial: 1-1/4" x 2" x 4-1/2"
- 74) Brick Partial: 1-1/4" x 4-1/2" x 3-1/2"
- 76) Brick Partial: 1-1/4" x 2" x 9"



[illegible]

Limited Lifetime Warranty

FPI Fireplace Products International Ltd. (for Canadian customers) and Fireplace Products U.S., Inc. (for U.S. customers) (collectively referred to herein as “FPI”) extends this Limited Lifetime Warranty to the original purchaser of this appliance provided the product remains in the original place of installation. The items covered by this limited warranty and the period of such coverage is set forth in the table below.

Some conditions apply (see below).

The policy is not transferable, amendable or negotiable under any circumstances.

| Wood Products | Component Coverage | | | | | Labor Coverage |
|---|---------------------------|---------|---------|--------|------------------|-----------------------|
| Components Covered | Lifetime | 5 years | 2 years | 1 year | Warranty | (Years) |
| Welded Firebox Steel | ✓ | | | | | 5 |
| All Stainless Steel Components, Smoke Deflectors, Heat Shields etc. | ✓ | | | | | 3 |
| Air Tubes | ✓ | | | | | 3 |
| Airmate | ✓ | | | | | 3 |
| Door handle and latch assembly, all hardware | ✓ | | | | | 3 |
| Glass Thermal Breakage Only | ✓ | | | | | 3 |
| Steel Faceplates, Accessory Housings | ✓ | | | | | 3 |
| All Plating | ✓ | | | | | 3 |
| Ash Drawer, Heatshields, Pedestal | ✓ | | | | | |
| All Baffles, Steel, Ceramic, Vermiculite | ✓ | | | | | |
| All castings, firebox, surrounds, doors, panels etc. | | ✓ | | | | 3 |
| All Electrical, Blower, wiring, switches etc. | | | ✓ | | | 2 |
| Glass - Crazing | | | | ✓ | | 1 |
| Catalyst Assembly | | | | | 6 Years Prorated | |
| Venting/Chimney | | | | ✓ | | 1 |
| Screens | | | | ✓ | | 1 |

Conditions:

Warranty protects against defect in manufacture or FPI factory assembled components only, unless herein specified otherwise.

Any part(s) found to be defective during the warranty period as outlined above will be repaired or replaced at FPI’s option through an accredited distributor, dealer or pre-approved and assigned agent provided that the defective part is returned to the distributor, dealer or agent for inspection if requested by FPI. Alternatively, FPI may at its own discretion fully discharge all of its obligations under the warranty by refunding the verified purchase price of the product to the original purchaser. The purchase price must be confirmed by the original Bill of Sale.

The authorized selling dealer, or an alternative authorized FPI dealer if pre-approved by FPI, is responsible for all in-field diagnosis and service work related to all warranty claims. FPI is not responsible for results or costs of workmanship of unauthorized FPI dealers or agents in the negligence of their service work.

At all times FPI reserves the right to inspect reported complaints on location in the field claimed to be defective prior to processing or authorizing of any claim. Failure to allow this upon request will void the warranty.

All warranty claims must be submitted by the dealer servicing the claim, including a copy of the Bill of Sale (proof of purchase by you). All claims must be complete and provide full details as requested by FPI to receive consideration for evaluation. Incomplete claims may be rejected.

Replacement units are limited to one per warranty term. Airtube and baffle replacements are limited to one replacement per term.

Unit must be installed according to all manufacturers' instructions as per the manual.

All Local and National required codes must be met.

The installer is responsible to ensure the unit is operating as designed at the time of installation.

The original purchaser is responsible for annual maintenance of the unit, as outlined in the owner's manual. As outlined below, the warranty may be voided due to problems caused by lack of maintenance.

Repair/replacement parts purchased by the consumer from FPI after the original coverage has expired on the unit will carry a 90 day warranty, valid with a receipt only. Any item shown to be defective will be repaired or replaced at our discretion. No labor coverage is included with these parts

Exclusions:

This Limited Lifetime Warranty does not extend to paint, rust or corrosion of any kind due to a lack of maintenance or improper venting, combustion air provision, corrosive chemicals (i.e. chlorine, salt, air, etc.), firebrick (rear, sides or bottom), door or glass gasketing, or any other additional factory fitted gasketing.

Malfunction, damage or performance based issues as a result of environmental conditions, location, chemical damages, downdrafts, installation error, installation by an unqualified installer, incorrect chimney components (including but not limited to cap size or type), operator error, abuse, misuse, use of improper fuels (such as unseasoned cordwood, mill-ends, construction lumber or debris, off-cuts, treated or painted lumber, metal or foil, plastics, garbage, solvents, cardboard, coal or coal products, oil based products, waxed cartons, compressed pre-manufactured logs), lack of regular maintenance and upkeep, acts of God, weather related problems from hurricanes, tornados, earthquakes, floods, lightning strikes/bolts or acts of terrorism or war, which result in malfunction of the appliance are not covered under the terms of this Limited Lifetime Warranty.

FPI has no obligation to enhance or modify any unit once manufactured (i.e. as products evolve, field modifications or upgrades will not be performed on existing appliances).

This warranty does not cover dealer travel costs for diagnostic or service work. All labor rates paid to authorized dealers are subsidized, pre-determined rates. Dealers may charge homeowner for travel and additional time beyond their subsidy.

Any unit showing signs of neglect or misuse will not be covered under the terms of this warranty policy and may void this warranty. This includes units with rusted or corroded fireboxes which have not been reported as rusted or corroded within three (3) months of installation/purchase.

Units which show evidence of being operated while damaged, or with problems known to the purchaser and causing further damages will void this warranty.

Units where the serial no. has been altered, deleted, removed or made illegible will void this warranty.

Minor movement, expansion and contraction of the steel is normal and is not covered under the terms of this warranty.

Freight damages for products or parts are not covered under the terms of the warranty.

Products made or provided by other manufacturers and used in conjunction with the FPI appliance without prior authorization from FPI may void this warranty.

Limitations of Liability:

The original purchaser's exclusive remedy under this warranty, and FPI's sole obligation under this warranty, express or implied, in contract or in tort, shall be limited to replacement, repair, or refund, as outlined above. IN NO EVENT WILL FPI BE LIABLE UNDER THIS WARRANTY FOR ANY INCIDENTAL OR CONSEQUENTIAL COMMERCIAL DAMAGES OR DAMAGES TO PROPERTY. TO THE EXTENT PERMITTED BY APPLICABLE LAW, FPI MAKES NO EXPRESS WARRANTIES OTHER THAN THE WARRANTY SPECIFIED HEREIN. THE DURATION OF ANY IMPLIED WARRANTY IS LIMITED TO DURATION OF THE EXPRESSED WARRANTY SPECIFIED ABOVE. IF IMPLIED WARRANTIES CANNOT BE DISCLAIMED, THEN SUCH WARRANTIES ARE LIMITED IN DURATION TO THE DURATION OF THIS WARRANTY.

Some U.S. states do not allow limitations on how long an implied warranty lasts, or allow exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you.

Customers located outside the U.S. should consult their local, provincial or national legal codes for additional terms which may be applicable to this warranty.

How to Obtain Warranty Service:

Customers should contact the authorized selling dealer to obtain warranty service. In the event the authorized selling dealer is unable to provide warranty service, please contact FPI by mail at the address listed below. Please include a brief description of the problem and your address, email and telephone contact information. A representative will contact you to make arrangements for an inspection and/or warranty service.

Canadian Warrantor:

FPI Fireplace Products International Ltd.
6988 Venture St.
Delta, British Columbia
Canada, V4G 1H4

U.S. Warrantor:

Fireplace Products U.S., Inc.
PO Box 2189 PMB 125
Blaine, WA
United States, 98231

Or contact the Regency Customer Care Centre at 1-800-442-7432 (phone) / 604-946-4349 (fax)

Product Registration and Customer Support:

Thank you for choosing a Regency Fireplace. Regency strives to be a world leader in the design, manufacture, and marketing of hearth products. To provide the best support for your product, we request that you complete a product registration form at <http://www.regency-fire.com/Customer-Care/Warranty-Registration.aspx> within ninety (90) days of purchase.



Product Registration and Customer Support:

Thank you for choosing a Regency Fireplace. Regency strives to be a world leader in the design, manufacture, and marketing of hearth products. To provide the best support for your product, we request that you complete a product registration form found on our Web Site under Customer Care within ninety (90) days of purchase.

For purchases made in **CANADA or the UNITED STATES:**

<http://www.regency-fire.com/Customer-Care/Warranty-Registration.aspx>

For purchases made in **AUSTRALIA:**

<http://www.regency-fire.com.au/Customer-Care/Warranty-Registration.aspx>

You may also complete the warranty registration form below to register your Regency Fireplace Product and mail and/or fax it back to us, and we will register the warranty for you. It is important you provide us with all the information below in order for us to serve you better.

Warranty Registration Form (or Register online immediately at the above Web Site):

| | |
|--|--|
| Warranty Details | |
| Serial Number (required): | |
| Purchase Date (required) (mm/dd/yyyy): | |
| Product Details | |
| Product Model (required): | |
| Dealer Details | |
| Dealer Name (required): | |
| Dealer Address: | |
| Dealer Phone #: | |
| Installer: | |
| Date Installed (mm/dd/yyyy): | |
| Your Contact Details (required) | |
| Name: | |
| Address: | |
| Phone: | |
| Email: | |

For purchases made in **CANADA:**

**FPI Fireplace Products
International Ltd.**
6988 Venture St.
Delta, British Columbia
Canada, V4G 1H4

Phone: 604-946-5155
Fax: 604-946-4349

For purchases made in the **UNITED STATES:**

Fireplace Products U.S., Inc.
PO Box 2189 PMB 125
Blaine, WA
United States, 98231

Phone: 604-946-5155
Fax: 604-946-4349

For purchases made in **AUSTRALIA:**

**Fireplace Products Australia Pty
Ltd**
1- 3 Conquest Way
Hallam, VIC
Australia, 3803

Phone: +61 3 9799 7277
Fax: +61 3 9799 7822

For fireplace care and tips and answers to most common questions please visit our Customer Care section on our Web Site. Please feel free to contact your selling dealer if you have any questions about your Regency product.

Installer: Please complete the following information

Dealer Name & Address: _____

Installer: _____

Phone #: _____

Date Installed: _____

Serial No.: _____



F2400 Video